

KnitPro®

FOR THOSE WHO LOVE TO KNIT

BOTTIES®

EMBROIDERED  
MOCCASINS



# MATERIAL REQUIRED

1. A pack of Botties basic
2. Pattern, Tracing paper
3. Felt Fabric for upper
4. Suede lining fabric
5. Embroidery threads
6. Fabric Fusing
7. Scissors
8. Thread
9. Strong Adhesive.

Click on the link to download pattern

[EMBROIDERED MOCCASINS](#)

# INSTRUCTION

- Step 1 : Print the patterns for both the upper and lining according to your shoe size by clicking the provided link.
- Step 2 : Trace the upper panels and cut them out carefully (don't forget the allowances).
- Step 3 : Trace the embroidery design following the provided pattern.
- Step 4 : Embroider the design with chosen colors.
- Step 5 : Apply fabric fusing to all upper panels for reinforcement.
- Step 6 : Stitch all the upper panels together.
- Step 7 : Trace and cut lining from suede fabric.
- Step 8 : Stitch the lining panels together.
- Step 9 : Attach the lining to the upper, stitching it from the wrong side at the neck.
- Step 10 : Apply contrasting top stitch on the edge of all the upper panels. (apron, counter, vamp).
- Step 11 : Cover the insole with suede fabric.
- Step 12 : Adhere the upper to insole using a strong adhesive.
- Step 13 : Use the provided nylon thread to create a false stitch in the soles and attach them to the insole using strong adhesive or directly stitch the insole to the sole.
- Step 14 : Apply botties tags on the outside of your shoes.
- Step 15 : Your embroidered moccasins are now ready to wear.

# TIPS & TRICKS

- Mark the centers on each panel while tracing.
- Secure the centers with pins while stitching to prevent displacement.
- Incorporate beads to enhance the artwork.

